





ROYAL VOGUE

Luxury Interior Emulsion

RETINA ROYAL VOGUE is a water-based luxury interior emulsion with an ultra-smooth, silky finish, offering washability, anti-algal, anti-fungal, and water-resistant properties.

FEATURES



High sheen and ultra smooth finish.













Low smell.





carcinogens, mutagens or reproductive toxins.

Excellent flow & brushability.



PRODUCT DETAILS

AVAILABLE PACKS



Available in 20 Litres, 10 Litres, 4 Litres and 1 Liter

COVERAGE

Only on the correctly prepared surface using brush and roller:

140 to 160 sft. /Litre/2 coats.



COLOURS AVAILABLE





COVERAGE

On smooth masonry surface by brushing



1 COAT 280 - 320 sq.ft/ltr**

RECOMMENDED USAGE









DIRECTIONS FOR USE

Recommended usage - On fresh or repainted masonry walls

PRE PAINTING STEPS



1. Plaster

New masonary surfaces must be allowed to cure completely. It is recommended to allow 28 days as the curing time for new masonary surfaces.



3. Filling of Cracks

For filling cracks upto 3mm use Retina Paints Smart Care Crack Seal.



2. Cleaning

Ensure that surface is completely free from all dirt, loosely held plaster, powdery residue, oil, grease or any other contamination. Any previous growth of fungus, algae or moss needs to be removed thoroughly by vigorous wire brushing and cleaning with water. One coat of Retina Paints SmartCare BioBlock is recommended to prevent further growth of algae, fungus or moss.



4. Covering of holes and dents

In case of dents and holes use Retina Paints Wall Putty or white cement and fine sand in the ratio 1:3

Special Instructions for Interior:

For interior surfaces or substrates that are subjected to continuous seepage or dampness, please check the source of leakage or seepage and ensure the same is rectified before application.



PAINTING STEPS



PRIMER APPLICATION
For both freshly plastered or repainting surface, apply one coat



PUTTY APPLICATION Smoothen the surface by filling dents and undulations. Allow it to dry for 4-6hours. Sand with sandpaper and wipe it.



PRIMER APPLICATION
Apply one coat of primer and
allow it to dry for minimum
4 hours.



TOP COAT APLLICATION Apply 2-3 coats of topcoat to ensure good hiding. A gap of 4-6 hours to be given after each coat.

APPLICATION PROCESS

APPLICATION	THINNER	DILUTION %	RECOATING PERIOD
STEP 1 SANDING	SAND	THE SURFACE WITH SAND PAPER 180	AND WIPE CLEAN
STEP 2 BASE COAT	WATER	30-40%	6 - 8 Hours
STEP 3 ACRYLIC WALL PUTTY	WATER	Based on Requirement	6 - 8 Hours
STEP 4 SANDING	SAND	THE SURFACE WITH SAND PAPER 180	AND WIPE CLEAN
STEP 5 BASE COAT	WATER	30-40%	6 - 8 Hours
STEP 6 FIRST COAT	WATER	20-30%	6 - 8 Hours
STEP 7 SECOND COAT	WATER	20-30%	6 - 8 Hours

 Recoat Peroid is quoted for 25°C and 50% Relative Humidity, these may vary under different conditions.

PRECAUTIONS

- Store in well ambient conditions, ventilated locations and away from sources of ignition and fire.
- Keep the container tightly closed to avoid the paint drying.
- Shake well after tinting.
- · Remove all the old paint thoroughly before painting.
- Do not apply when ambient temperature might drop to a level below 10°C or above 45°C.
- · Do not apply on damp wall and lime washed surfaces.
- · For deep shades apply one additional coat.
- Use safety equipment like rubber or polythene gloves, safety goggles / glasses & face mask.
- In case of eye / skin contact, wash with plenty of water.
- Inhalation / Injection is dangerous. In either case, move to fresh air & consult a medical practitioner.

TECHNICAL DETAILS

Gloss levels	Rich sheen	
Dry time	3-4 Hrs.	
Pot life of thinned material	Within 24 Hrs.	
Flash point	NA	
Washable	Excellent	
Fire hazard class	Non-flammable	

SURFACE PREPARATION AND APPLICATION

- Ensure that the surface is clean, dry and free from dirt, grease, wax, fungus and algae.
- Cover all the fine cracks with RETINA WALL FIX and large cracks may need cement work. Allow the sufficient time for the putty to dry.
- Apply the first coat RETINA PRIMER and allow it to dry for 6 to 8 hours.
- Smoothen the surface by applying thin coats of RETINA WALL FIX to fill all the dents and allow the putty to dry overnight.
- Sand the surface with emery paper and apply the second coat of RETINA PRIMER and allow it to dry for 6 to 8 hours.
- Sand the surface with Emery paper and clean the surface with cloth before painting.
- Finally, apply two to three coats of RETINA ROYAL VOGUE emulsion as per recommended thinning. Dark shades may require additional coat for hiding.

